

**Kit Contents:**

High Impact resistant joint mould

Resin - required to completely fill the mould

Sealant Tape for sealing mould onto cable

Disposable PVC gloves

Cut the stepped mould ends to suit the outside diameter of the cable being used.

Mix the resin in its transparent pouch and pour contents into mould until it is completely full.

*Setting the Standards in Cable Jointing*